Regal Liquid Soap Dispenser (White)

User manual and wall mounting guide

Product code LIQSOAP-DPS. A clear, re-typed copy of the manufacturer instruction sheet supplied with the dispenser, so it can be read on screen and printed. Figures are reproduced from the original sheet.

Specifications


Dimensions	115 (L) x 110 (W) x 245 (H) mm
Capacity	1000 ml
Output per press	1.5 ml (liquid soap), 0.4 ml (foam), 0.3 ml (spray)
Weight	469 g
Material	ABS

Pump heads

The same housing takes three pump heads: a foam pump, a spray pump and a liquid soap pump. The sheet marks the **soap pump** for this dispenser. To change what the unit dispenses, swap to the matching pump head.



Installation




Step 1 (Figure A). Use the supplied key to open the front cover.

Step 2 (Figure B). 1. Pull the front panel in the direction of the arrow and separate it from the back shell.
2. Push the pump head to the left and lift out the bottle.
3. Hold the back shell against the wall as a template and mark where to drill the mounting holes.
4. Drill the marked holes and insert the supplied wall plugs.
5. Screw the back shell to the wall with the supplied screws.

Step 3 (Figure C). Foam pump only: put 30% liquid soap into the bottle, then 70% clean water, close the lid and mix. Not needed for the liquid soap pump.

Step 4 (Figure D). Refit the bottle in the dispenser and fill it with liquid.

Step 5 (Figure E). A disposable bag can be used instead of the bottle.



Operation figures from the original instruction sheet.

Advice

Soap strength differs between regions. If liquid soap does not come out when you press, empty the bottle, refill with a thinner soap (or dilute it with water) and try again. Each unit is water tested in production, so a few drops of water inside a new dispenser are normal.

Care and maintenance

- Keep objects out of the outlet. If the bottle is dirty or has debris, rinse the soap out, clean it and refill.
- If the dispenser is not used for a long time, the liquid soap may thicken and set. Rinse it out before refilling.
- Do not clean with corrosive chemical cleaners, which can damage or deform the surface.
- If the dispenser leaks, replace the pump head.

Supplied by Mega Office Supplies. megaofficesupplies.com.au. 1300 783 961.