

wellcare

LED POCKET MIRROR



USER MANUAL

Model Number: HT-MD03



Contents

03	General Safety Warnings
06	Getting Started
07	Product Overview
08	Operation
09	Specifications

General Safety Warnings

For the safety of yourself and others, follow all instructions and take notice of all the warnings. When adhered to, these safety precautions can reduce the risk of fire, electric shock and injury.

This product complies with Australian Safety standard AS/NZS 60598.1 and 60598.2.4 to ensure the safety of the product.



The RCM is a visible indication of a product's compliance with all applicable ACMA regulatory arrangements, including all technical and record-keeping requirements.



This product is a class III equipment and is designed to be supplied by a Separated Extra-Low Voltage (SELV) power source.

IMPORTANT

Environment: Do not use this product where it is excessively hot, cold, dusty or humid, or where it is exposed to strong magnetic fields or long periods of sunshine.

Water: Do not expose this product to water; do not use it where it can fall into water (such as near a pool, pond, bath etc.).

Handling: Do not drop this product or shake it vigorously to avoid damaging it.

Accessories: Only use the device with the accessories that are supplied. Use of other accessories not recommended in this manual may cause damage to the product and will void your warranty.

Usage: Only operate the device according to the instructions in this manual. We assume no responsibility for faulty use or inappropriate handling.

Usage: The equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a person responsible for their safety.

General Safety Warnings

Children: Supervise young children to ensure they do not play with the device inappropriately. Close supervision is necessary when the device is used by or near children.

Cleaning: Clean the housing of the device lightly with a dry or moist cotton cloth. Do not use alcohol, thinners, benzene or any other chemical cleaners.

Damage: In case of damage, contact the After Sales Support line for advice.

Disposal: Observe local regulations and dispose of this device appropriately for recycling. Contact your local authorities for advice on facilities.

Unpacking the product: Unpack the product and keep the original packaging carton and materials in a safe place. It will help prevent any damage if the product needs to be transported in the future, and you can use it to store the product when it is not in use.

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture; do not use it anywhere near water.

Keep the device dry. Do not let the device come into contact with water vapour or operate it with wet hands. Contact with water will cause the device to short-circuit, corrode or cause electric shock.

Do not shake the equipment excessively, which may cause device or battery failure, fire or explosion.

The light source of this product is not replaceable, when the light source reaches its end of life, the whole product shall be replaced.

Do not expose the device to very low or very high temperatures, which may cause device or battery failure, fire or explosion.

Do not disassemble the device and accessories. Disassembly by unauthorised persons will void the warranty.

Do not use the device while driving, so as not to impede safe driving regulations.

Do not replace the battery with an incorrect type that can defeat a safeguard.

Do not dispose of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

Do not expose the battery to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Safety information

- The product must only be used for its intended purpose as described in the manual. Using the product for any other purpose invalidates the warranty.
- Improper use may result in a risk of fire.
- This product is not for commercial use.
- The product can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the product.
- Do not use the product if it shows any signs of damage, if it is not in perfect working order, or if it has been dropped to become damp.
- Do not attempt to repair the product yourself in the event of a malfunction since this will invalidate the warranty. Repairs should only be carried out by authorised service centres.
- Do not cover up the product when it is switched on. Never use it under blankets or cushions.
- Use the product only in dry rooms, and in no case when bathing or showering.
- Do not use the product near petrol or other easily flammable substances.
- Turn the product off after each use and before cleaning it.
- Cleaning and user maintenance shall not be made by children without supervision.



CAUTION, RISK OF ELECTRIC SHOCK

Getting Started


Before first use

- Unpack the product and accessories and ensure all parts of the product are undamaged and in good working order. Keep the original packaging carton and materials in a safe place. It will help prevent any damage if the product needs to be transported in the future, and you can use it to store the product when it is not in use. In the event that the packaging is to be disposed of, please recycle all packaging materials where possible.
- Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach and disposed of safely.
- Do not use the product if any part is damaged or not working properly. In case of damage, contact our after sales support line for advice.
- Read this manual to familiarise yourself with the product. Pay particular attention to the safety instructions on the previous pages.

What's in the box:

- LED Pocket Mirror
- USB-C Charging Cable
- Instructional Manual
- Warranty Card

Product Overview



- 1 8X Magnifying Mirror
- 2 Make-up LED Light
- 3 Touch Switch Sensor (Power Switch)
- 4 USB-C Charging Port
- 5 Charging Indicator Light (Light will turn red when the device is charging and Light will turn blue when it is fully charged).

Operation

The Mirror is powered by a 600mAh battery. Make sure that the battery is fully charged before use.

Using the LED Mirror



To turn on the mirror light, tap the power switch



To adjust the brightness of the light, press and hold the switch



To change light modes, tap the switch to cycle through warm, cool, and daylight light.



To turn off the light, tap the power switch

Charging the LED Mirror

- 1 Connect the Type-C charging port to a 5V power supply or computer using the provided Type-C cable.
- 2 When charging begins, the indicator will turn on. Once the mirror is fully charged, the indicator will turn blue.
- 3 Before charging the mirror, ensure that the switch is off

Specifications

Material	Glass/ABS (For Mirror)
Battery	3.7V, 600mAh
Ambient Temperature	5°C - 40°C
Power	DC5V, 1A, 5W

For Technical and Warranty Support

1300 886 649

tempo.org/support

Distributed by Tempo (Aust) Pty Ltd,
PO BOX 6097, North Sydney NSW 2059

Notes

Notes

wellcare



Please read the manual

It will help you get the best out of your product.

Still have questions?

Call After Sales Support
1300 886 649
Or visit tempo.org/support



Please scan the QR code to access the latest manual.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on (AU) 1300 886 649 or (NZ) 0800 836 761 for advice.

Distributed by Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO BOX 6097, North Sydney NSW 2059

Customer Helpline:

(AU) 1300 886 649 (NZ) 0800 836 761

Email: tempo.org/support

www.wellcarehealthproducts.com